

## **Firmware Update Method**


*NOTE*: There are 2 parts to this firmware update. You will need a formatted USB Thumb Drive to complete the update.

## Part 1 - CPU Firmware Update

1. Download the firmware update onto your desktop of your PC or laptop.



2. Unzip the downloaded file and you will see the below folder on your desktop.



3. Open the unzipped folder. Format your USB thumb drive and copy the below file to it.

N CL 11 1700 00000 1001 CD11						
╞ СММ720_20200403АСРU						
파일 홈 공유 보기						
	잘라내기 경로 복사 바로 가기 붙여넣기	이동 복사 위치 * 위치 *	★ ■ 삭제 이름 ★ 바꾸기	[	<ul> <li>✓ 월기 ▼</li> <li>◆ 편집</li> <li>◆ 히스토리</li> </ul>	➡ 모두 선택 응 선택 안 회 문 선택 영역
클립보드		7	년성	새로 만들기	열기	선택
🛃 📕 🖛						
← → ∨ ↑ 🖹 > CMM72	0_20200403ACPU	i				<b>י טֿ</b> כאו
	<b>^</b> 0	~ 름	수정한 날찌	자 유형	크기	
★ 바로 가기		dvdrom				KD
Description	*	avarom	2020-04-0.	3 오후 2:47 ALZip BIN	l File 8,464	KB
Documents	<b>x</b> = 0					
Me Documents	*					
	~					
💺 사진	*					
<mark>-</mark> 사진 Ĵ SDHC (E:)	*					
1 사진 Ĵ SDHC (E:) ▶ 내 PC	*					
▶ 사진 ③ SDHC (E:) ▶ 내 PC ▶ 3D 개체	*					
⊾ 사진 ③ SDHC (E:) ● 내 PC 월 3D 개체 ☞ Documents	*					
⊾ 사진 ③ SDHC (E:) ● 내 PC ⑤ 3D 개체 ⓒ Documents 爲 다운로드	*					
<ul> <li>▶ 사진</li> <li>③ SDHC (E:)</li> <li>● 내 PC</li> <li>③ 3D 개체</li> <li>№ Documents</li> <li>● 다운로드</li> <li>● 동영상</li> </ul>	*					
<ul> <li>▶ 사진</li> <li>③ SDHC (E:)</li> <li>&gt; 내 PC</li> <li>③ 3D 개체</li> <li>☑ Documents</li> <li>질 다운로드</li> <li>질 동영상</li> <li>잘 바탕 화면</li> </ul>	*					
<ul> <li>▲ 사진</li> <li>③ SDHC (E:)</li> <li>● 내 PC</li> <li>④ 3D 개체</li> <li>☑ Documents</li> <li>● 다운로드</li> <li>필 동영상</li> <li>逼 바탕 화면</li> <li>▲ 사진</li> </ul>	*					
<ul> <li>▲ 사진</li> <li>③ SDHC (E:)</li> <li>● 내 PC</li> <li>④ 3D 개체</li> <li>☑ Documents</li> <li>▲ 다운로드</li> <li>필 동영상</li> <li>● 바탕 화면</li> <li>▲ 사진</li> <li>③ 음악</li> </ul>	*					
<ul> <li>↓ 사진</li> <li>③ SDHC (E:)</li> <li>● 내 PC</li> <li>⑤ JD 개체</li> <li>⑥ Documents</li> <li>○ 다운로드</li> <li>⑥ 동영상</li> <li>● 바탕 화면</li> <li>↓ 사진</li> <li>③ 음악</li> <li></li> <li></li> <li></li> <li></li> <li>로컬 디스크 (C:)</li> </ul>	*					

4. Insert the USB thumb drive into the USB input on the front of the radio.

	) Radi	io			12	:46 РМ
	F		)7.	.90	Loc P1 MHz	•
				O STERED	AS/P	
1	7.50	<sup>2</sup> 90.10	³ 98.10	₄ 106.10	₅ 107.90	<sup>6</sup> 87.50
ALE	<b>X</b>	Q	) = JENS	-		

5. Once inserted the below screen will be displayed. Press the Green  $\sqrt{1000}$  to begin.



6. Once the update as started successfully, you will see the Green color bar to show the status of the update.

54 1-1	Upgrading.Do not power off!	
2.14	JENSEN	


7. Once the update is complete you will see the below screen. Remove the USB thumb drive and turn your vehicle off and then back on. This will complete the 2<sup>nd</sup> part of the update.




## Part 2 - MCU Firmware Update

1. Download the firmware update onto your desktop of your PC or laptop.





3. Open the unzipped folder. Format your USB thumb drive and copy the below file to it.



2. Unzip the downloaded file and you will see the below folder on your desktop.


4. Insert the thumb drive into the USB input on the front of the radio.



5. Once inserted the below screen will be displayed. Press the **Green**  $\sqrt{\text{icon}}$  to begin.



6. Once the update as started successfully, you will see the Green color bar to show the status of the update.



7. Once the update is complete you will see the below screen. Remove the USB thumb drive and turn your vehicle off and then back on. This will complete the 1<sup>st</sup> part of the update.



## **Checking the Firmware Version**

1. Press the Setting Icon on the Main Menu screen or Radio Mode screen.

	Rac	lio			12	:46 рм	
Ĩ X C		-M1 ]( @	<b>)7</b> . 8	.9( ∞			
Media Port	<sup>1</sup> 87.50	<sup>2</sup> 90.10	LOCAL/DX 3 98.10	STERED 4 106.10	45/P \$ 107.90	s 687.50	
2.1A			JENS	JEN			

2. Touch the arrow to the right of the Version text in the Settings menu as shown below.

Set	tting 💼 💼 🛊 12:46 ам ᠫ
ن ت	Beep
	<u>Camera</u>
ax interaction of the second	Version ►
	Restore Default
MEDIA PORT	
2.1A	JENSEN USBMIRROR &

3. If your receiver displays the below updated firmware versions, than your receiver is now up to date.

