

J1CA10FL

QUICK START GUIDE

Media Receiver with Android Auto™ and CarPlay™ featuring a 10.1" digital TFT Display




This Quick Start Guide gives you the basics to start using your J1CA10FL. Please visit https://www.jensenmobile.com

to download a complete owner's manual or call customer service at 1-888-921-4088 (Monday-Friday, 9AM-5PM EST).

Designed and Engineered in USA



Wiring Diagram - Inputs/Outputs




When replacing a fuse, make sure to use the correct type and amperage. Using an incorrect fuse could cause damage. The unit uses (1) 15 amp ATC mini style fuse located on the power connector.

Installation

For detailed installation instructions, please refer to the included Installation Guide

Screen Adjustments



Control Locations

The radio display features the following functions and displays:

- 1 Voice Activation Button SOURCE/HOME
- Power/Volume/Mute (4) Previous Button
- (5) Next Button
- (6) RESET



1 Main Menu

Local/Distance

(4) Seek Tune Up

(5) Seek Tune Down

(6) Preset Stations

(2) Dimmer

7) EQ

8 Settings

Main Menu

In main menu, press the desired icon to enter the corresponding mode: AM/FM/Bluetooth Phone/ Bluetooth Audio/Apple CarPlay/Android Auto/USB/ Camera/EQ /AV In/Settings



Tuner Operation



USB Operation

Audio Operation

Screen Operation

General Operation

Displa

Wi-Fi

Wired connection

Wireless connection

2. Press the Apple CarPlay icon.

function on the Phone.

1. Press icon on the main menu;

The Apple CarPlay home screen appears

2. Press " \(\sigma \)" to confirm to use wireless CarPlay:


7 Press " \(\sigma \)" on the screen to confirm to connect.

5. A pass key will be displayed on the screen;

Date and Time and other radio Settings.

ate & Time

From the main menu, touch the USB icon on the main screen.



Select from the below 3 icons in the Settings menu to select between Balance, Fader and Time

Alignment Settings, EQ Presets and 10-Band EQ Settings or Surround Settings.

Press the Monitor icon in the Settings menu to access the Brightness, Contrast,

Press the Function icon in the Settings menu to access the Time Zone,

Wired & Wireless CarPlay Operation

1. Connect an Apple CarPlay compatible device to this unit via USB.

Before using Apple CarPlay wirelessly, turn on the Bluetooth/Wifi

4. Find the desired device on the screen and press "Pair"

3. Press " C "icon to search phone device. The available devices appear on the list;

6. The same key appears on the iPhone, press "Pair" and then press "Allow" for the popups;

Wired & Wireless Android Auto™ Operation

8. Press "Use CarPlay" on the iPhone. The unit configures the connection then starts the application

Wi-Fi

- R1 -

Fader **-** 0

Button Illumination Colors and Wallpaper Settings.

- (1) Main Menu
- (2) Current Mode Indicator
- (3) Repeat
- (4) Random
- (5) List
- (6) ID3 Tag Display Area (7) Track Down
- 8 Play/Pause
- 9 Track Up 10 Album Art

Press to display keypad and dial a number.

will not automatically connect to any device.

Bluetooth Operation

cated. This is also referred to as "pairing" a device.

formed. On certain phones, pairing may need to be done more than once.

The head unit will automatically connect to the last connected

If the connect feature is set to Auto Connect Off, the head unit

Bluetooth icon will appear anytime a Bluetooth device is con-

device when the connect feature is set to Auto connect On.

From the main menu. touch the **Bluetooth** on the screen.

Before using Bluetooth

Pairing a New Device

Making and Ending a Call

Press to connect a call, and press nto end a call.

Transferring Audio

Press [] to transfer andio between the head unit and mobile

Streaming Audio

Press > to play or pause the music.

Press I to skip to the previous track.

Press ▶ to advance to the next track.

Rear Camera



Limited Two Year* Warranty

This warranty gives you specific legal rights. You may also have other rights which vary from state to state. Jensen warrants this product to the original purchaser to be free from defects in material and workmanship for a period of two years from the date of the original purchase

Before you can use a Bluetooth device to make hands-free calls or stream audio. it must be authenti-

The unit broadcasts the pairing signal constantly when no devices are currently connected. Complete

the pairing sequence from your Bluetooth device. Refer to the owner's manual for your device for more

details. The device name is "J1CA10FL". The unit can be in any mode of operation when pairing is per-

7 (8 (9 wxyz)

Jensen agrees, at our option, during the warranty period, to repair any defect in material or workmanship or to furnish an equal new, renewed, or comparable product (whichever is deemed necessary) in exchange without charges, subject to verification of the defect or malfunction and proof of the date of purchase. Subsequent replacement products are warranted for the balance of the original warranty period.

What is covered? This warranty covers all defects in the material and workmanship in this product. The following are not covered: software, installation/removal costs, damage resulting from accident, misuse, abuse, neglect, product modification, improper installation, incorrect line voltage, unauthorized repair, or failure to follow instructions supplied with the product, or damage occurring during return shipment of the product. Specific license conditions and copyright notices for the software can be found via www.jensenmobile.com.

Warranty Coverage

* Limited 2-year warranty. (Proof of purchase required)

Jensen recommends professional installation of any electronics in your vehicle to ensure the best

1. Before you call for service, check the troubleshooting guide in your owner's manual. A slight adjustment of any custom controls may save you a service call.

2. If you require service during the warranty period, you must carefully pack the product (preferably in the original package) and ship it by prepaid transportation with a copy of the original receipt from the retailer to an authorized service center.

3. Please describe your problem in writing and include your name, a return UPS shipping address (P.O. Box not acceptable), and a daytime phone number with your shipment.

4. For more information and for the location of the nearest authorized service center please contact

us by one of the following methods:

· Call us toll-free at (888) 921-4088 (Monday-Friday, 9:00 am, to 5:00 pm, EST)

E-mail us at cs@jensenmobile.com

Exclusion of Certain Damages: This warranty is exclusive and in lieu of any and all other warranties,

expressed or implied, including without limitation the implied warranties of merchantability and fitness for a particular purpose and any obligation, liability, right, claim or remedy in contract or tort, whether or not arising from the company's negligence, actual or imputed. No person or representative is authorized to assume for the company any other liability in connection with the sale of this product. In no event shall the company be liable for indirect, incidental, or consequential damages.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

www.jensenmobile.com © 2023 Namsung America Inc. All rights reserved. NSC0723-V01

Before using Android Auto wirelessly, turn on the Bluetooth/Wifi function on the Android device. 1. Press \Lambda icon on the main menu;

2. Press "

" to confirm to use wireless Android Auto;

The Android Auto home screen appears.

2. Press the Android Auto icon.

Wireless connection

3. Press "Q"icon to search phone device. The available devices appear on the list;

1. Connect an Android Auto™ compatible device to this unit via USB

4. Find the desired device on the screen and press "Pair"; 5. A pass key will be displayed on the screen;

6. The same key appears on the Android device, press "Pair" and then press "Allow" for the popups; 7. Press " \(\sigma \)" on the screen to confirm to connect:

The unit configures the connection then starts the application.